Clavos Installation Instructions

1. Locate clavos on door at desired locations.
2. Using masking tape, mark the location of the clavos on the door.
3. Moisten a clean cloth with 70% isopropyl alcohol and clean the area where the clavos will be applied.
4. Remove backing tape from the tape on one clavos and attach it to the door. NOTE: Clavos cannot be removed once placed on the door.
5. Press the clavos firmly in place at the location of the tape backer. 35 pounds of force is required.
6. Repeat for each clavos.